



314 South Broadway, Rt. 28, Salem, NH 03079
Tel: 603-898-9946 1-800-869-7251
Email: GetFit@FescoFitnessEquipment.com

Elliptical Maintenance Tips

For More Information Contact:

Fitness & Equipment Supply Company ~ 314 South Broadway, Rt. 28, Salem, NH 03079
Tel: 603-898-9946 Fax: 603-898-6640

NOTE: This material is offered for information purposes only. For complete safety information please contact the manufacturer of the equipment. Be certain to follow ALL safety procedures as advised by the manufacturer or contact the fitness equipment professionals at FESCO for information and assistance.

IMPORTANT NOTE: Read your equipment owner's manual.

Just reading through your owner's manual may save you from costly repairs. All maintenance procedures should be listed in the owner's manual, along with troubleshooting guidelines, parts listings, and instructions for repairs. Damage to your equipment from improper use or unauthorized tampering can result in the manufacturer voiding the warranty.

Be Healthy, Be Safe.

-Thank you from all of us at FESCO.

Electronic Issues

Issue: Unit doesn't power up:

- Check the connection of the power cord from the machine to the wall outlet.
- Plug a lamp or radio into the outlet to see if the wall outlet has power.
- If a light switch controls the outlet, turn it on.
- Check to see that the light on the power supply lights up.
- If you have verified power from the outlet, you may have a faulty power supply.
- Contact Fitness & Exercise Supply Co. at (603) 898-9946 for assistance.

Issue: Console blinks on/off:

- Check the power cord connections.
- Make sure the connections are secure from the transformer into the machine base and to the wall outlet.
- The console connections could be faulty. Refer to the assembly instructions and check connections.
- If the issue persists contact Fitness & Exercise Supply Co. at (603) 898-9946 for assistance.

Issue: Console does not work:

- The console connections could be faulty. Refer to the assembly instructions and check connections.
- If the issue persists contact Fitness & Exercise Supply Co. at (603) 898-9946 for assistance.

If your elliptical computer console repeatedly or frequently crashes, then it may need to be replaced. Contact Fitness & Exercise Supply Co. at (603) 898-9946 for assistance.



314 South Broadway, Rt. 28, Salem, NH 03079
Tel: 603-898-9946 1-800-869-7251
Email: GetFit@FescoFitnessEquipment.com

Mechanical Issues

Issue: Handlebars are loose/wobble side to side:

- The screws securing the moving handlebars to the pivot shaft must be very tight.
- Refer to the assembly instructions and remove the handlebar covers and tighten these screws.

Issue: Handlebars are loose/wobble front to back:

- **IMPORTANT: Contact your local dealer for service.**

Issue: Machine wobbles and is unstable on the floor:

- The adjustable levelers may not be properly set on the machine. There are our adjustable levelers, located on the bottom of the elliptical. See assembly instructions to correctly adjust and lock the levelers.
- If your machine is located on a soft surface such as carpet, you may wish to stabilize the unit by purchasing a heavy duty floor mat from Fitness & Exercise Supply, Co. to place under your machine.